

CE

UPM 3100



Universal Power Meter

Use and Programming *English*

General contents

	GENERAL CONTENTS	A
CHAPTER 1	INTRODUCTION	1-1
CHAPTER 2	GRAPHIC SYMBOLS.....	2-1
CHAPTER 3	PRECAUTIONARY MEASURES	3-1
CHAPTER 4	EQUIPMENT USE.....	4-1
	4.1 Layout	4-1
	4.2 Push-button station	4-1
CHAPTER 5	MAIN MENU.....	5-1
	5.1 Page layout	5-1
	5.2 Real time	5-3
	5.2.1 <i>List of pages</i>	5-3
	5.2.2 <i>Symbols</i>	5-5
	5.2.3 <i>Power factor compensation</i>	5-6
	5.2.4 <i>Page display</i>	5-7
	5.3 Energy counters	5-8
	5.3.1 <i>List of pages</i>	5-8
	5.3.2 <i>Input counter</i>	5-10
	5.3.3 <i>Symbols</i>	5-10
	5.3.4 <i>Main display</i>	5-10
	5.3.5 <i>Input counter reset</i>	5-10
	5.4 Demand & Peak	5-11
	5.4.1 <i>List of pages</i>	5-11
	5.4.2 <i>Symbols</i>	5-14
	5.4.3 <i>Page display</i>	5-14
	5.4.4 <i>Reset</i>	5-14
	5.5 Min/Max	5-15
	5.5.1 <i>List of pages</i>	5-15
	5.5.2 <i>Symbols</i>	5-16
	5.5.3 <i>Page display</i>	5-16

5.5.4	Zeroing	5-17
5.6	Oscilloscope	5-18
5.6.1	List of pages	5-18
5.6.2	Page display	5-20
5.7	Harmonics	5-21
5.7.1	List of pages	5-21
5.7.2	Under limit indication	5-22
5.7.3	Set-up of full scale	5-23
5.7.4	Page display	5-23
5.8	Profiles	5-24
5.8.1	List of pages	5-24
5.8.2	Page description	5-25
5.8.3	Set-up	5-25
5.8.4	Page display	5-26
5.9	Utility Setup	5-27
5.9.1	Contrast adjustment	5-27
5.9.2	Meter and counter reset	5-27
5.9.3	Clear Demands	5-29
5.9.4	Clear Peaks	5-29
5.9.5	Clear Min/Max	5-30
5.9.6	Clear records	5-30
5.9.7	Set default	5-30
5.10	Info	5-31
5.10.1	List of pages	5-31

CHAPTER 6 MAIN SETUP MENU 6-1

6.1	Access to and quitting the Main Setup menu	6-1
6.1.1	Access	6-1
6.1.2	Quit	6-3
6.2	Page layout	6-3
6.3	Main	6-5
6.3.1	Energy counters	6-5
6.3.2	Synchronisation mode	6-6
6.3.3	Synchronisation frequency	6-6
6.3.4	Average power integration time (DMD Time)	6-7
6.4	Communication	6-8
6.5	Memory	6-9
6.5.1	Save mode	6-9
6.5.2	File list	6-10
6.5.3	File information	6-11

6.5.4	<i>Newfile</i>	6-12
6.5.5	<i>Start/Stop</i>	6-13
6.5.6	<i>Formatting</i>	6-13
6.6	<i>Timebands</i>	6-14
6.6.1	<i>Example of time period programming</i>	6-15

CHAPTER 7 TECHNICAL FEATURES 7-1

7.1	<i>Available versions</i>	7-1
7.2	<i>Technical data</i>	7-2
7.2.1	<i>Electromagnetic compatibility</i>	7-5
7.3	<i>Performed measurements</i>	7-6
7.4	<i>Formulas</i>	7-7
7.5	<i>Functions available upon request</i>	7-8
7.5.1	<i>Communication protocol</i>	7-8
7.5.2	<i>Power supply</i>	7-8
7.5.3	<i>Voltage drops</i>	7-8
7.5.4	<i>Minimum, average and maximum values</i>	7-8
7.5.5	<i>LPR40 Printer</i>	7-9
7.6	<i>Software</i>	7-10
7.6.1	<i>Wintool</i>	7-10
7.6.2	<i>Dedalo SP</i>	7-10

1. Introduction

This Manual provides information on how to install and program the instrument. The box also contains an additional Manual, providing installation and set-up instructions.

Both Manuals are not intended for general use, but for qualified technicians.

This term indicates a professional and skilled technician, authorised to act in accordance with the safety standards relating to the dangers posed by electric current.

This person must also have basic first aid training and be in possession of suitable Personal Protective Equipment.



WARNING!

It is strictly forbidden for anyone who does not have the above-mentioned features to install or use the device.

The device complies with the European Union directives in force, as well as with the technical standards implementing these requirements, as certified by the EC mark on the device and on this Manual.

Using the tool for purposes other than intended ones, deducible by the manual content, is strictly forbidden.

The manufacturer reserves the right to modify the device and/or technical specifications included in this Manual.

The Manufacturer shall not shoulder any responsibility for any use of the instrument which is different from that illustrated in this manual and in the *Installation and configuration manual*, or for non- /imperfect application of the specified instructions.

The information herein contained shall not be shared with third parties. Any duplication of this manual, either partial or total, not authorised in writing by the Manufacturer and obtained by photocopying, duplicating or using any other electronic means, violates the terms of copyright and is punishable by law.

The information contained in this manual and in the Installation and Configuration Manual was carefully checked at the time of publication. However, the Manufacturer does not accept liability for any inaccuracy, errors, missing updates, and reserves the right to modify the device and / or documentation without prior notice.

Any brands quoted in the publication belong to the legitimate registered owners.

NOTE

This Manual refers to the complete instrument version. Some displays may not be available if the instrument was purchased without some functions.

2. Graphic symbols

Some instructions in the Manual and on the device are highlighted by graphic symbols to draw the reader's attention to the operational dangers.

The following graphic symbols are used:



DANGER !

This warning indicates the possible presence of voltage higher than 1kV on the marked terminals (even for short periods).



WARNING!

This warning indicates the possible occurrence of an event which may cause a serious accident or considerable damage to the device if suitable precautionary countermeasures are not taken.



ATTENTION!

This warning indicates the possible occurrence of an event which may cause a light accident or damage to the device if suitable precautionary countermeasures are not taken.

NOTE

This warning indicates important information which must be read carefully.

3. Precautionary measures

In standard operation mode, the instrument is connected with power sources that are potentially dangerous for operators. The connecting terminals of the power supply cables, the voltage and current transformers and the digital and analog inputs and outputs are powered.



WARNING!

Electrocution may cause serious accidents and eventually fatal injuries.


This is why the instrument must be installed, programmed and used by skilled and trained technicians. See chapter 1 for the definition of “skilled technician”.

After the installation, the terminals to which cables are connected must be inaccessible.

The equipment complies with the 89/366, 73/23 regulations and following amendments. However, if not properly installed, it may generate a magnetic field and radio interference. The EMC regulations on electro-magnetic compatibility and the instructions contained in the *Installation and Configuration Manual* must be complied with.

4. Equipment use


4.1 Layout



4.2 Push-button station

Here below is a list of the main functions.

The special functions, depending on the displayed page, are described in the relevant paragraphs.



1-2 ARROW KEYS

Normal display mode

- a Press them to go to a different page or to move the cursor to the available options.


Programming mode

- a Move the selection cursor to the available options.
- b Modify the value of the figure (or group of figures) identified by the cursor.

3 MENU BUTTON

Normal display mode

- a press it for at least 3 seconds to display the main menu
- b scrolls pages in the OSCILLOSCOPE, HARMONICS and HISTOGRAM functions.



Programming mode

- a To enter the password, press it together with (4).
- b Moves the selection cursor to the right-hand side figure
- c To exit the programming mode, keep it pressed for at least 3 seconds.

4 MAIN BUTTON

Normal display mode

- a Keep it pressed for at least 3 seconds to set the current page as main page.
- b Keep it pressed for at least 3 seconds on the main page to delete it.
- c To display the main page, press it together with (5).
- d Scrolls pages in the OSCILLOSCOPE, HARMONICS and HISTOGRAM functions.

Programming mode

- a To enter the password, press it together with (3).
- b Moves the selection cursor to the left-hand side figure.

5 ENTER KEY

Normal display mode

- a Confirms the selection and displays the selected function.
- b To display the main page, press it together with (4).

For connection with an LP40 printer:

- c Press it together with (3) to enter the manual print menu.
- d Press it together with (1) to print the displayed page.
- e Press it together with (2) to move the paper forward.

Programming mode


- a Confirms the entered selection. Use the keys (1) and (2) to change the values.
- b Confirms the modified values.

If the display light is off, press any one of the five keys to turn it on (it will stay on for the set time, as described in the section 8.12 of the Installation and Configuration Manual).

5. Main menu



To enter the Main Menu keep any key pressed for at least 3 seconds.




1	REAL TIME	Section 5.2
2	ENTERGY COUNTERS	Section 5.3
3	DEMAND & PEAK	Section 5.4
4	MIN/MAX	Section 5.5
5	OSCILLOSCOPE	Section 5.6
6	HARMONICS	Section 5.7
7	PROFILES	Section 5.8
8	UTILITY SETUP	Section 5.9
9	MAIN SETUP	Chapter 6
10	INFO	Section 5.10



5.1 Page layout

The following page shows the Main Menu structure.

To enter any page, move the cursor to the relevant description and press .

Main Menu



4	5	6
V	A	W
V1 000.4 V2 00.00 V3 00.00 ccw ↻	kA1 000.4 kA2 00.00 kA3 00.00 kAN 00.12	kW1 00.00 kW2 00.00 kW3 00.00
7	8	9
PF	Cos φ	VA
PF1 0.004 ∟ PF2 0.000 ∟ PF3 0.000 ∟	0.998 ∟ 0.961 ∟ 0.982 ∟ 	kVA1 000.4 ∟ kVA2 00.00 ∟ kVA3 00.00 ∟
10	11	12
var	L1	L2
kvar1 000.4 ∟ kvar2 00.00 ∟ kvar3 00.00 ∟	V 000.4 kA 00.00 kW 00.00 PF 0.412 ∟	V 000.4 kA 00.00 kW 00.00 PF 0.412 ∟
13	14	15
L3	THD	THD
V 000.4 kA 00.00 kW 00.00 PF 0.412 ∟	>> V << THD1% 000.4 THD2% 000.0 THD3% 000.0	>> A << THD1% 000.4 THD2% 000.0 THD3% 000.0
16	17	18
Cos φ	Cos φ	Target : 0.920
Cosφ1 000.4 ∟ Cosφ2 000.0 ∟ Cosφ3 000.0 ∟	0.998 ∟ 0.961 ∟ 0.982 ∟ 	Cos φ var L1 0.848 ∟ 0016.2k L2 0.850 ∟ 0015.6k L3 0.852 ∟ 0015.3k ΣL 0.850 ∟ 0047.1k

- 1 Voltage, current, active power, system power factor.
- 2 System active, reactive and apparent power
- 3 Phase and frequency linked voltages
- 4 Phase voltage and phase rotation sequence
- 5 Phase and neutral currents
- 6 Active phase powers
- 7 Phase power factors
- 8 Voltage-current vectorial chart (on PF)
- 9 Apparent phase powers
- 10 Reactive phase powers
- 11 Voltage, current, active power, L1 phase power factor.
- 12 Voltage, current, active power, L2 phase power factor.
- 13 Voltage, current, active power, L3 phase power factor.
- 14 Percentage distortion index of phase voltage
- 15 Percentage distortion index of phase currents
- 16 Phase CosØ
- 17 Voltage-current vectorial chart (on CosØ)
- 18 Re-phasing

5.2.2 Symbols

Some pages contain the following symbols.

		ΣP
MW	00.00	
Mvar	00.00	μL
MVa	00.00	μL


The symbol L refers to an inductive load; the symbol C indicates a capacitive load. These symbols are located next to cosØ, reactive power and reactive energy consumption

The symbol - placed before the Active power, indicates the exported energy.

		V
V1	000.4	
V2	00.00	
V3	00.00	
	ccw	⌚

Phase rotation indication:
CW (Clock Wise) = sequence, L1 - L2 - L3.
CCW (Counter Clock Wise) = sequence, L1 - L3 - L2

The figure below shows the geometric representation of active and reactive power and power factor, in compliance with the EN611268 Norm.



NOTES:

- 1 The chart refers to the current vector "I" (on the RH-side).
- 2 The direction of the voltage vector "V" changes depending on the phase displacement angle ϕ
- 3 The displacement angle ϕ between voltage "V" and current "I" is positive in the trigonometric expression (counter-clockwise).

5.2.3 Power factor compensation

This function calculates the power of the re-phasing capacitors (var), which are necessary to raise the measured $\text{Cos}\phi$ to the requested value (Objective).

Target : 0.920	
Cos φ	var
L1 0.848	0016.2k
L2 0.850	0015.6k
L3 0.852	0015.3k
ΣL 0.850	0047.1k

- 1 Press  to set a new Objective value;
- 2 Choose one of the available values using the keys   ;
- 3 To confirm the selected value press .

5.2.4 Page display

The values displayed in the REAL TIME section may change depending on the electrical connections (see chapter 7 of the Installation and Configuration Manual for the connections). The table below shows the displayed values depending on the connection type.

PAGE	DISPLAY VALUES	Connection Type							
		3 ph., 4 wires 3 current transformers	3 ph., 3 wires 3 current transformers	3 ph., 3 wires 2 current transformers	3 ph., 3 wires 1 current transformer	3 ph., 1 wire 3 current transformers	1 ph., 3 wires 2 current transformers	1 ph., 3 wires 1 current transformer	
ΣL	V, A, W, PF	X	X	X	X	X	X	X	X
ΣP	W, var, VA	X	X	X	X	X	X	X	X
Harm	ThdV, ThdA, Cos Φ , Hz								X
ΔV	V_{12}, V_{23}, V_{31} , Hz V_{12} , Hz	X	X	X	X		X	X	
V	V_{1N}, V_{2N}, V_{3N} V_{1N}, V_{2N}	X						X	
A	A_1, A_2, A_3, A_N A_1, A_2, A_3 A_1, A_2, A_N	X		X	X		X		
W	W_1, W_2, W_3 W_1, W_2	X						X	
PF	PF_1, PF_2, PF_3 PF_1, PF_2	X						X	
Fresnel PF	$A_1, A_2, A_3, V_1, V_2, V_3$ A_1, A_2, V_1, V_2 A_1, V_1	X						X	X
VA	VA_1, VA_2, VA_3 VA_1, VA_2	X						X	
VAR	var_1, var_2, var_3 var_1, var_2	X						X	
ΣL_1	V, A, W, PF	X						X	
ΣL_2	V, A, W, PF	X						X	
ΣL_3	V, A, W, PF	X							
THD-V	V_{1N}, V_{2N}, V_{3N} V_{1N}, V_{2N}	X						X	
THD-A	A_1, A_2, A_3 A_1, A_2 A_1, A_3 A_1	X	X		X		X	X	
Cos Φ	$Cos\Phi_1, Cos\Phi_2, Cos\Phi_3$ $Cos\Phi_1, Cos\Phi_2, Cos\Phi$							X	
Fresnel Cos Φ	$A_1, A_2, A_3, V_1, V_2, V_3$ A_1, A_2, V_1, V_2 A_1, V_1	X						X	X
Pw. compensat.	var_1, var_2, var_3 var_1, var_2, var var_1	X						X	X

5.3 Energy counters

MENU
Real Time
Energy Counters
Demand & peak
Min/Max
Oscilloscope
Harmonics
Profiles
Utility Setup
Main Setup
Info

The pages of this section display the energy counters.

1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.

2 Move the highlight bar to ENERGY

	Wh-varh
MWh	+75391.5
Mvarh	≡ 24391.5
Mvarh	÷ 01043.6
MVAh	+75391.5

COUNTERS by means of the keys 

 and press .

3 When in the menu, press  or  to scroll the available pages.

5.3.1 List of pages

The instrument shows the energy consumption divided into time periods.

Two pages display the total data in real time; eight more pages (4 for imported and 4 for exported energy) show the energy consumption divided per tariff period for the current and previous day and for the current and previous month.

If the input card DI4-TR is installed (optional), the page described in the next paragraph is also present.

The following sequence is shown as it appears when the key is pressed for each display.

1	2	3																																														
<table border="1"> <tr><td></td><td>Wh-varh</td></tr> <tr><td>MWh</td><td>+75391.5</td></tr> <tr><td>Mvarh</td><td>≡ 24391.5</td></tr> <tr><td>Mvarh</td><td>÷ 01043.6</td></tr> <tr><td>MVAh</td><td>+75391.5</td></tr> </table>		Wh-varh	MWh	+75391.5	Mvarh	≡ 24391.5	Mvarh	÷ 01043.6	MVAh	+75391.5	<table border="1"> <tr><td></td><td>Wh-varh</td></tr> <tr><td>MWh</td><td>- 75391.5</td></tr> <tr><td>Mvarh</td><td>≡ 24391.5</td></tr> <tr><td>Mvarh</td><td>÷ 01043.6</td></tr> <tr><td>MVAh</td><td>- 75391.5</td></tr> </table>		Wh-varh	MWh	- 75391.5	Mvarh	≡ 24391.5	Mvarh	÷ 01043.6	MVAh	- 75391.5	<table border="1"> <tr><td></td><td>P. MONTH</td></tr> <tr><td>MWh</td><td>1 +08549.6</td></tr> <tr><td>Mvarh</td><td>1 ≡06030.8</td></tr> <tr><td>Mvarh</td><td>1 ÷00819.0</td></tr> <tr><td>MVAh</td><td>1 +02285.2</td></tr> <tr><td>MWh</td><td>2 +10305.3</td></tr> <tr><td>Mvarh</td><td>2 ≡07332.2</td></tr> <tr><td>Mvarh</td><td>2 ÷02211.3</td></tr> <tr><td>MVAh</td><td>2 +05228.4</td></tr> <tr><td>MWh</td><td>3 +20738.6</td></tr> <tr><td>Mvarh</td><td>3 ≡10354.3</td></tr> <tr><td>Mvarh</td><td>3 ÷03820.4</td></tr> <tr><td>MVAh</td><td>3 +10086.8</td></tr> </table>		P. MONTH	MWh	1 +08549.6	Mvarh	1 ≡06030.8	Mvarh	1 ÷00819.0	MVAh	1 +02285.2	MWh	2 +10305.3	Mvarh	2 ≡07332.2	Mvarh	2 ÷02211.3	MVAh	2 +05228.4	MWh	3 +20738.6	Mvarh	3 ≡10354.3	Mvarh	3 ÷03820.4	MVAh	3 +10086.8
	Wh-varh																																															
MWh	+75391.5																																															
Mvarh	≡ 24391.5																																															
Mvarh	÷ 01043.6																																															
MVAh	+75391.5																																															
	Wh-varh																																															
MWh	- 75391.5																																															
Mvarh	≡ 24391.5																																															
Mvarh	÷ 01043.6																																															
MVAh	- 75391.5																																															
	P. MONTH																																															
MWh	1 +08549.6																																															
Mvarh	1 ≡06030.8																																															
Mvarh	1 ÷00819.0																																															
MVAh	1 +02285.2																																															
MWh	2 +10305.3																																															
Mvarh	2 ≡07332.2																																															
Mvarh	2 ÷02211.3																																															
MVAh	2 +05228.4																																															
MWh	3 +20738.6																																															
Mvarh	3 ≡10354.3																																															
Mvarh	3 ÷03820.4																																															
MVAh	3 +10086.8																																															

4

P. MONTH		
MWh	1	-08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	-02285.2
MWh	2	-10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	-05228.4
MWh	3	-20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	-10086.8

5

MONTH		
MWh	1	+08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	+02285.2
MWh	2	+10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	+05228.4
MWh	3	+20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	+10086.8

6

MONTH		
MWh	1	-08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	-02285.2
MWh	2	-10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	-05228.4
MWh	3	-20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	-10086.8

7

YESTERDAY		
MWh	1	+08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	+02285.2
MWh	2	+10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	+05228.4
MWh	3	+20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	+10086.8

8

YESTERDAY		
MWh	1	-08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	-02285.2
MWh	2	-10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	-05228.4
MWh	3	-20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	-10086.8

9

TODAY		
MWh	1	+08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	+02285.2
MWh	2	+10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	+05228.4
MWh	3	+20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	+10086.8

10

TODAY		
MWh	1	-08549.6
Mvarh	1	06030.8
Mvarh	1	+00819.0
MVAh	1	-02285.2
MWh	2	-10305.3
Mvarh	2	07332.2
Mvarh	2	+02211.3
MVAh	2	-05228.4
MWh	3	-20738.6
Mvarh	3	10354.3
Mvarh	3	+03820.4
MVAh	3	-10086.8

- 1 Consumption of imported active, reactive and apparent energy
- 2 Consumption of exported active, reactive and apparent energy
- 3 Consumption of imported active, reactive and apparent energy divided per tariff period (previous month)
- 4 Consumption of exported active, reactive and apparent energy divided per tariff period (previous month)
- 5 Consumption of imported active, reactive and apparent energy divided per tariff period (current month)
- 6 Consumption of exported active, reactive and apparent energy divided per tariff period (current month)
- 7 Consumption of imported active, reactive and apparent energy divided per tariff period (yesterday)
- 8 Consumption of exported active, reactive and apparent energy divided per tariff period (yesterday)
- 9 Consumption of imported active, reactive and apparent energy divided per tariff period (yesterday)
- 10 Consumption of exported active, reactive and apparent energy divided per tariff period (today)

5.3.2 Input counter

If the DI4-TR card is installed (4 digital inputs, optional), the page shown to the side is present. The total energy sent to each input is displayed on this page.

Each input can be assigned a different multiplying factor in the PROGRAMMING menu (see next chapter).

MWh1	INPUT
00051371.5	
MWh2	00005692.6
MWh3	00731331.2
MWh4	00000593.0

5.3.3 Symbols

	Wh-varh
MWh	- 75391.5
Mvarh	⊖ 24391.5
Mvarh	⊕ 01043.6
MVAh	- 75391.5

The symbol \ominus indicates an inductive load; the symbol \oplus indicates a capacitive load. These symbols are located next to the items concerning the reactive energy consumption (Mvarh).

The sign - indicates that the value refers to an exported unit.

5.3.4 Main display

	Wh-varh
MWh	- 75391.5
Mvarh	⊖ 24391.5
Mvarh	⊕ 01043.6
MVAh	- 75391.5

Active energy consumption

Inductive reactive energy consumption

Capacitive reactive energy consumption

Apparent energy consumption

5.3.5 Input counter reset

The totalizers of total energy, time-specific energy and the digital input counters can be separately reset.

See section 5.9 for these operations.

5.4 Demand & Peak

MENU
Real time
Energy Counters
Demand & Peak
Min/Max
Oscilloscope
Harmonics
Profiles
Utility Setup
Main Setup
Info

The pages of this section display the min. and max. values of the main measurements.

1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.

2 Move the highlight bar to DEMAND&PEAK by means of the keys   and press



3 When in the menu, press  or  scroll the available pages

		DMD
A1	0308	
A2	0307	
A3	0304	
An	0028	

5.4.1 List of pages

The following list may vary depending on the connection scheme (see section 5.2.4). The sequence refers to a 3-phase, 4-wire, 3-current connection scheme, as shown when the key is pressed for each display.

The pages with the **DMD** abbreviation on the upper right-hand side refer to average values. The pages with **PEAK** refer to peak values.

1		2		3	
				DMD	
A1	0308	kW	0194	A	0308
A2	0307	kVa	0201	kvar	0030 ξ
A3	0304	W/VA	0.965	kvar	0003 \div
An	0028				

4

DMD	
A1	- 0308
A2	- 0307
A3	- 0304
An	- 0028

5

DMD	
kW	- 0194
kVa	- 0201
W/VA	- 0.965

6

DMD	
A	- 0308
kvar	- 0030 ξ
kvar	- 0003 \ddagger

AVERAGE VALUES (DMD)

List of average values

- 1 Phase current 1, 2, 3 and neutral (purchase)
- 2 System active and apparent power (purchase). Ratio between active and apparent power (PF)
- 3 System current, system inductive reactive power and system capacitive reactive power (purchase)
- 4 Phase current 1, 2, 3 (sale)
- 5 System active and apparent power (sale). Ratio between active and apparent power (PF)
- 6 System current, system inductive reactive power and system capacitive reactive power (sale)

7

Peak	
Jul 15 08:56:42	
A1 Pdmd +0318.	
Jul 15 08:55:45	
A2 Pdmd +0318.	
Jul 15 08:56:40	
A3 Pdmd +0318.	
Jul 15 08:55:32	
An Pdmd 0033.	

8

Peak	
Jul 15 08:58:42	
kW Pdmd +0196.	
kVA dmd +0205.	
kvar ξ dmd +0025.	
W/VA ξ dmd +0.956	

9

Peak	
Jul 15 08:56:12	
kVA Pdmd +0205.	
kW dmd +0196.	
kvar \ddagger dmd +0025.	
W/VA \ddagger dmd +0.956	

10

Peak	
Jul 15 08:51:20	
kvar ξ Pdmd +0025.	
kW dmd +0196.	
kVA dmd +0205.	
W/VA ξ dmd +0.956	

11

Peak	
Jul 15 08:44:34	
kvar \ddagger Pdmd +0001.	
kW dmd +0098.	
kVA dmd +0102.	
W/VA \ddagger dmd +0.961	

12

Peak	
Jul 15 08:56:42	
A1 Pdmd -0318.	
Jul 15 08:55:45	
A2 Pdmd -0318.	
Jul 15 08:56:40	
A3 Pdmd -0318.	

13

Peak	
Jul 15	08:58:42
kW	Pdmd - 0196.
kVA	dmd - 0205.
kvar	dmd - 0025.
W/VA	dmd - 0.956

14

Peak	
Jul 15	08:56:12
kVA	Pdmd - 0205.
kW	dmd - 0196.
kvar	dmd - 0025.
W/VA	dmd - 0.956

15

Peak	
Jul 15	08:51:20
kvar	Pdmd - 0025.
kW	dmd - 0196.
kVA	dmd - 0205.
W/VA	dmd - 0.956

16

Peak	
Jul 15	08:44:34
kvar	dmd - 0001.
kW	dmd - 0098.
kVA	dmd - 0102.
W/VA	dmd - 0.961

PEAK VALUES

List of detected peak values (of average values)

- 7 Phase current 1, 2, 3 and neutral (purchase)
- 8 System active power (purchase). The following average values are also recorded together with this value: system apparent power, system reactive power (inductive or capacitive), ratio between active and apparent power (PF)
- 9 System apparent power (purchase). The following average values are also recorded together with this value: system active power, system reactive power (inductive or capacitive), ratio between active and apparent power (PF)
- 10 System reactive inductive power (purchase). The following average values are also recorded together with this value: system active power, system apparent power, ratio between active and apparent power (PF)
- 11 System reactive capacitive power (purchase). The following average values are also recorded together with this value: system active power, system apparent power, ratio between active and apparent power (PF)
- 12 See point 7 (sale)
- 13 See point 8 (sale)
- 14 See point 9 (sale)
- 15 See point 10 (sale)
- 16 See point 11 (sale)

5.4.2 Symbols

	Peak
Jul 15	08:58:42
kW	Pdmd - 0196.
kVA	dmd - 0205.
kvar $\frac{m}{-}$	dmd - 0025.
W/VA $\frac{m}{-}$	dmd - 0.956

Some pages contain the following symbols.

The symbol $\frac{m}{-}$ indicates an inductive load; the symbol $\frac{m}{+}$ indicates a capacitive load.

The sign - indicates that the value refers to an exported unit (sale).

5.4.3 Page display

The values displayed in the DEMAND&PEAK section may change depending on the electrical connections (see chapter 7 of the Installation and Configuration Manual for the connections).

The table below shows the displayed values depending on the connection type.

PAGE	DISPLAYED VARIABLES								
		3ph., 4 wires 3current trasformers	3ph., 3 wires 3current trasformers	3ph., 3 wires 2current trasformers	3ph., 3 wires 1current trasformer	3ph., 1 wire 3current trasformers	1ph., 3 wires 2current trasformers	1ph., 2 wires 1current trasformer	
A DMD	A_1, A_2, A_3, A_N	X							
	A_1, A_2, A_3		X	X					
	A_1, A_2, A_N						X		
W DMD	W, VA, W/VA	X	X	X	X	X	X	X	
	A, var i, var c	X					X	X	
	var i, var c		X	X	X	X			
A DMD PEAK	A_1, A_2, A_3, A_N	X							
	A_1, A_2, A_3		X	X					
	A_1, A_2, A_N						X	X (A_1)	
W DMD PEAK	W, VA, var, W/VA	X	X	X	X	X	X	X	
VA DMD PEAK	VA, W, var, W/VA	X	X	X	X	X	X	X	
var DMD PEAK	var, W, VA, W/VA	X	X	X	X	X	X	X	

5.4.4 Reset

The average values and peak values of average values can be separately reset. See section 5.9 for these operations.

5.5 Min / Max

MENU
Real time
Energy Counters
Demand & Peak
Min/Max
Oscilloscope
Harmonics
Profiles
Utility Setup
Main Setup
Info

The pages of this section display the minimum and maximum values detected by the instrument. Date and time are shown for all the available measurements

		Min./Max.
Feb 19		20:37:59
V		m+000.3
Feb 19		20:31:32
V		M+040.0
Feb 19		20:41:23
V1		m+000.5
Feb 19		20:31:32
V1		M+061.0

- 1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.
- 2 Move the highlight bar to MIN/MAX by means of the keys   and press .
- 3 When in the menu, press  or  to scroll the available pages.

5.5.1 List of pages

The following list may vary depending on the connection scheme (see section 5.2.4). The sequence refers to a 3-phase, 4-wire, 3-current connection scheme, as shown when the key  is pressed for each display.

1	2	3
Min./Max.	Min./Max.	Min./Max.
Feb 19	Feb 19	Feb 19
V	V2	A
Feb 19	Feb 19	Feb 19
V	V2	A
Feb 19	Feb 19	Feb 19
V1	V3	A1
Feb 19	Feb 19	Feb 19
V1	V3	A1

4			5			6		
		Min./Max.			Min./Max.			Min./Max.
Feb 19		20:37:59	Feb 19		20:37:59	Feb 19		20:37:59
kA2		m+000.3	MW		m+000.3	PF		m+000.3
Feb 19		20:31:32	Feb 19		20:31:32	Feb 19		20:31:32
kA2		M+040.0	MW		M+040.0	PF		M+040.0
Feb 19		20:41:23	Feb 19		20:41:23	Feb 19		20:41:23
kA3		m+000.5	MVA		m+000.5	var		m+000.5
Feb 19		20:31:32	Feb 19		20:31:32	Feb 19		20:31:32
kA3		M+061.0	MVA		M+061.0	var		M+061.0

- | | |
|---|---|
| 1 Minimum (m) and maximum (M) values of V and V1. | 4 Minimum (m) and maximum (M) values of A ₂ and A ₃ . |
| 2 Minimum (m) and maximum (M) values of V ₂ and V ₃ . | 5 Minimum (m) and maximum (M) values of W and VA. |
| 3 Minimum (m) and maximum (M) values of A and A ₁ . | 6 Minimum (m) and maximum (M) values of PF and var. |

5.5.2 Symbols

		Min./Max.	
Feb 19	V	20:37:59	← m = min. value
	V	m+000.3	← M = max. value
Feb 19	V	20:31:32	← m = min. value
	V1	M+040.0	← M = max. value
Feb 19	V1	20:41:23	
	V1	m+000.5	
Feb 19	V1	20:31:32	
	V1	M+061.0	

5.5.3 Page display

The values displayed in the MIN/MAX section may change depending on the electrical connections (see chapter 7 of the Installation and Configuration Manual for the connections).

The table below shows the displayed values depending on the connection type.

PAGE	DISPLAY VALUE								
		3 ph, 4 wires 3 current transformers	3 ph, 3 wires 3 current transformers	3 ph, 3 wires 2 current transformers	3 ph, 3 wires 1 current transformers	3 ph, 1 wire 3 current transformers	1 ph, 3 wires 2 current transformers	1 ph, 2 wires 1 current transformers	
V, V ₁	V, V ₁	X					X		
	V		X	X	X	X			
	V ₁								X
V ₂ , V ₃	V ₂ , V ₃	X							
	V ₂							X	
A, A ₁	A, A ₁	X	X	X	X	X	X	X	
	A ₁								X
A ₂ , A ₃	A ₂ , A ₃	X	X	X			X		
	A ₂							X	
W, VA	W, VA	X	X	X	X	X	X	X	X
PF, Var	PF, Var	X	X	X	X	X	X	X	X



5.5.4 Zeroing

All minimum and maximum values can be zeroed.

See section 5.9 for this operation.

After zeroing the values, the instrument will show “—.” till the next measurement different from 0 (zero).

5.6 Oscilloscope



The pages of this section graphically show the current and voltage waves of each phase (L1, L2, L3).


- 1 Press and keep it pressed for at least 3 seconds. The main menu will be displayed.
- 2 Move the highlight bar to OSCILLOSCOPE by means of the keys and press .
- 3 When in the menu, press or to scroll the available pages.
- 4 When inside a phase, press or to display the graphics.

5.6.1 List of pages

The following list may vary depending on the connection scheme (see section 5.2.4). The sequence refers to a 3-phase, 4-wire, 3-current connection scheme, as shown when the key is pressed for each display. Press or to display additional pages for each phase.

The pages show the following data:

- graphics;
- RMS value (phase – neutral);
- THD;
- frequency;
- PF (Power factor)
- Min/max peaks;



- 1 Graphic/numeric display of voltage, phase 1
- 2 Graphic/numeric display of current, phase 1
- 3 Graphic/numeric display of voltage/current, phase 1
- 4 Graphic/numeric display of voltage, phase 2
- 5 Graphic/numeric display of current, phase 2
- 6 Graphic/numeric display of voltage/current, phase 2
- 7 Graphic/numeric display of voltage, phase 3
- 8 Graphic/numeric display of current, phase 3
- 9 Graphic/numeric display of voltage/current, phase 3



5.6.2 Page display

The values displayed in the OSCILLOSCOPE section may change depending on the electrical connections (see chapter 7 of the Installation and Configuration Manual for the connections).

The table below shows the displayed values depending on the connection type.

PAGE	DISPLAY VALUE								
		3 ph, 4 wires 3 current transformers	3 ph, 3 wires 3 current transformers	3 ph, 3 wires 2 current transformers	3 ph, 3 wires 1 current transformers	3 ph, 1 wire 3 current transformers	1 ph, 3 wires 2 current transformers	1 ph, 2 wires 1 current transformers	
L1	V_1, A_1, V_1, A_1	X					X	X	
	A_1		X	X	X	X			
L2	V_2, A_2, V_2, A_2	X					X		
	A_2		X			X			
L3	V_3, A_3, V_3, A_3	X							
	A_3		X	X		X			

5.7 Harmonics



The pages of this section show the current and voltage harmonic content.


- 1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.
- 2 Move the highlight bar to HARMONICS by means of the keys   and press .
- 3 When in the menu, press  or  to scroll the available pages.
- 4 When in the display, press  or  to access the data pages.

5.7.1 List of pages

The following list may vary depending on the connection scheme (see section 5.2.4). The sequence refers to a 3-phase, 4-wire, 3-current connection scheme, as shown when the key is pressed for each display.

Press  or  to display additional pages.


The instrument provides a percentage graphic or numeric display of the three voltage and current values, up to the 50th harmonics. The numeric display pages show percentage or absolute values.




1 Graphic representation of harmonics.
Three pages for voltage values (V1, V2, V3) and three pages for currents (I1, I2, I3).

2-3-4-5
Percentage values (from the 1st to the 50th harmonics)

6-7-8-9
Absolute values (from the 1st to the 50th harmonics)




5.7.2 "Under limit" indication



The harmonic analysis is not performed when the voltage values are lower than the full scale values by 5% or if the current values are 0.5% lower.

The message "Under Limit" is shown in these cases.

5.7.3 Set-up of full scale



To set the full scale:

- 1 Press  to display the bar showing the full scale percentage.
- 2 Press  or  to increase or decrease the full scale percentage (from 1 to 15%).
- 3 Press  to confirm. The bar disappears and the new value is stored.


5.7.4 Page display

The data shown in the HARMONICS section may change depending on the electrical connections (see chapter 7 of the Installation and Configuration Manual for the connections).


The table below shows the displayed values depending on the connection type.

PAGE	DISPLAY VALUE								
		3 ph, 4 wires 3 current transformers	3 ph, 3 wires 3 current transformers	3 ph, 3 wires 2 current transformers	3 ph, 3 wires 1 current transformers	3 ph, 1 wire 3 current transformers	1 ph, 3 wires 2 current transformers	1 ph, 2 wires 1 current transformers	
V ₁	V ₁	X						X	X
V ₂	V ₂	X						X	
V ₃	V ₃	X							
A ₁	A ₁	X	X	X	X	X	X	X	X
A ₂	A ₂	X	X				X	X	
A ₃	A ₃	X	X	X			X		

5.8 Profiles



The pages of this section show the histogram of the min/max values. The dates of the current and previous day can be displayed.



1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.


2 Move the highlight bar to PROFILES by means of the keys   and press .

3 When in the menu, press  or  to scroll the available pages.

5.8.1 List of pages


The following list may vary depending on the connection scheme (see section 5.2.4). The sequence refers to a 3-phase, 4-wire, 3-current connection scheme.

Press  or  to display the histogram of units **(A)**. Press  or  to change the displayed time (24 hours) **(C)**. The indicator **(B)** on top of the page shows the displayed period.




Value of (A): V, V1, V2, V3, A, A1, A2, A3, W, VA, PF, var


5.8.2 Page description



5.8.3 Set-up



- 1 Press  to display the bar showing the full scale percentage.



2 Press  or  to increase or decrease the full scale percentage, respectively (from 1 to 15%).

3 Press  to confirm. The bar disappears and the new value is stored. A horizontal cursor is displayed (A).

4 Press  or  to change the position of the cursor (A) and show the corresponding absolute value (B).

5.8.4 Page display


The displayed pages of the HISTOGRAM section may change depending on the electrical connection (see chapter 7 of the Installation and Configuration Manual for the connections).

The table below shows the displayed values depending on the connection type.

PAGE	DISPLAYED VARIABLES								
		3 ph., 4 wires 3 current transformers	3 ph., 3 wires 3 current transformers	3 ph., 3 wires 2 current transformers	3 ph., 3 wires 1 current transformer	3 ph., 1 wire 3 current transformers	1 ph., 3 wires 2 current transformers	1 ph., 2 wires 1 current transformer	
V	Valore min/max di V	X	X	X	X	X	X	X	X
V ₁	Valore min/max di V ₁	X						X	
V ₂	Valore min/max di V ₂	X						X	
V ₃	Valore min/max di V ₃	X							
A	Valore min/max di A	X	X	X	X	X	X	X	X
A ₁	Valore min/max di A ₁	X	X	X	X	X	X	X	
A ₂	Valore min/max di A ₂	X	X	X		X	X		
A ₃	Valore min/max di A ₃	X	X	X		X			
W	Valore min/max di W	X	X	X	X	X	X	X	X
VA	Valore min/max di VA	X	X	X	X	X	X	X	X
PF	Valore min/max di PF	X	X	X	X	X	X	X	X
var	Valore min/max di var	X	X	X	X	X	X	X	X

5.9 Utility Setup


The pages of this section are accessed to adjust the contrast and reset.




1 Press  and keep it pressed for at least 3 seconds. The main menu will be displayed.

2 Move the highlight bar to UTILITY SETUP of the keys   and press .

3 Move the highlight bar to the requested menu by means of the keys   and press .



5.9.1 Contrast adjustment




To adjust the display contrast,  click on the space bar on CONTRAST ADJUSTMENT.


Press  to decrease the contrast and,  to increase it. Press  to confirm.

5.9.2 Meter and counter reset




To reset the energy meters and the digital input counters (see section 5.3) follow the procedure below:



1 Move the highlight bar to CLEAR COUNTERS by means of the keys and press and press .




2 Move the highlight bar to the words which describe the counters to be reset by means of the keys (system counters, time periods, digital inputs, all). Press .



3 Regardless of the type of operation, the instrument will ask to confirm before resetting the counters ("NO" is the default answer. Press if you do not want to reset) .


To reset, select "YES" by means of the keys; then press to confirm.




4 When the password is requested, press the keys **MENU** simultaneously within 5 seconds. The counter will be reset. The figure shows the time period display.

5.9.3 Clear Demands

To zero the average values of the main measurements (DEMAND, see section 5.4) follow the procedure below.




- 1 Move the highlight bar to CLEAR DEMANDS by means of the keys and press .




- 2 The instrument will ask to confirm before resetting ("NO" is the default answer. Press if you do not want to zero).

To reset, select "YES" by means of the keys , then press to confirm.




- 3 When the password is requested, press the keys simultaneously within 5 seconds. The zeroing will be made.

5.9.4 Clear Peaks




To zero the maximum values of the main measurements (PEAK, see section 5.4) follow the procedure described under section 5.9.3.

5.9.5 Clear Min/Max




To zero the minimum and maximum values (MIN/MAX, see section 5.5) follow the procedure described under section 5.9.3.

5.9.6 Clear records





To zero the records, follow the procedure described under section 5.9.3.

5.9.7 Set default



Thanks to the initialisation, the default parameters of the instrument can be restored. Follow the procedure described under section 5.9.3.

5.10 Info




- 1 Press  and keep it pressed for at least 3 seconds. The Main Menu will be displayed.
- 2 Move the highlight bar to INFO by means of the keys   and press .
- 3 When in the menu, press  or  to scroll the available pages.

5.10.1 List of pages

The following list may change depending on the system configuration.

The sequence is shown and displayed when the key  is pressed.

1	2	3
<p>UPM 3100 Universal Power Meter 2Mb Ram S.N. ZIWHC0003 Release 1.00</p>	<p>INPUT SETUP Three-Phase 4 wires/3 CT Direct Input 250 V Max CT Value : 0005 A Curr. In.: 5 A</p>	<p>3 Phases - 4 Wires/3 CT</p> 
4	5	6
<p>CONFIGURATION Digital Out Harmonics-50 Flash 2 Mb</p>	<p>ACTUAL SETUP Storage OFF Printer OFF Main Page ON Average 15 min Frequency AUTO</p>	<p>CLOCK Date 92/02/19 Time 20:11:11 Day Saturday</p>

7


REC. STATUS
F01 En ON
Used Spc :00.5 kB

- 1 Identification data (instrument name, memory, serial number, firmware version)
- 2 Type of connection and ratios of voltmetric and amperometric transformers
- 3 Connection diagram
- 4 I/O configuration (available options)
- 5 Programmed functions
- 6 Date, time and day of the week
- 7 Information on programmed recording

If the CPU2 is installed, an additional page providing information on the programmed recording is also available (VDR0P-VMAX options).

6. Main Setup menu

Access the Main Setup menu from the Main Menu by moving the highlight bar to MAIN SETUP and pressing .



NOTE

When the Main Setup menu is entered, the instrument stops the measurement, recording, calculation and communication processes. The outputs, if any, remain in the status they were in before entering the programming mode.

The Manual refers to the complete instrument version. Some displays may not be shown if the instrument was purchased without including some functions.

See the section below for the methods to enter or quit the Main Setup menu.

1	MAIN	Section 6.3
2	WIRING	Chapter 8.9 Installation Manual
3	COMMUNICATION	Section 6.4
4	PRINTER	Manual of the LPR40 printer
5	MEMORY	Section 6.5
6	CLOCK	Chapter 8.8 Installation Manual
7	TIMEBANDS	Chapter 6.6
8	IN/OUT-ALARMS	Chapter 8.11 Installation Manual + I/O Options Manual

6.1 Access to and quitting the Main Setup menu


6.1.1 Access

The procedure described in this section must be performed whenever access to the Main Setup menu is needed.



1 Recall the Main Menu by pressing  for at least 3 seconds.


2 Press  or  until Main Setup is selected. Press  to confirm.



When the password is requested press   simultaneously.

The warning shown in the previous picture is displayed whenever the Main Setup menu is accessed.

When this function is entered, printing and communication with the PC are inhibited.



3 Press  or  to select YES.

To confirm press .

6.1.2 Quit

To quit the Main Setup menu, press  for at least 3 seconds. A page requesting confirmation will be displayed.

The following options are available:

YES to confirm, save and quit programming. This is the default option. To confirm press .

NO to quit without saving and exit the Main Setup menu.

CONTINUE to remain in the Main Setup menu.


To choose NO or CONTINUE, press  or  and  to confirm.

6.2 Page layout

The following page shows the structure of the Main Setup menu. To enter any page, move the cursor to the corresponding page and press



Main Setup Menu



6.3 Main

SETUP	
Main	
Wiring	
Communication	
Printer	
Memory	
Clock	
Timebands	
In/Out - Alarms	

The pages in this section show some instrument set-up data.

- 1 In the Main Setup menu, move the highlight bar to MAIN and press  .

MAIN	
Curr. In.	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz	Auto
Hz	5000
Language	ENG
DMD Time	15
Previous	

- 2 To scroll the items, press  or  .

NOTE

Some items of the Main Menu (Curr.In, Volt.In., B.Light, SerialP, Language) are not described in the following paragraphs because they are dealt with in the Installation and Configuration Manual.

6.3.1 Energy counters

MAIN	
Curr. In	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz	Auto
Hz	5000
Language	ENG
DMD Time	15
Previous	

The item En. Count. is used to change the meter resolution.

Move the highlight bar as shown in the picture, press  to enable, change,   or confirm the selection  . The following options are available:

- Vel.** High resolution. Small quantities of energy update the meter. In max. consumption mode, the meter is completed in 6 days. Suitable to measure consumption over short periods.

Len. Standard resolution. The meter is updated more slowly than in the “Vel” option. The meter is completed in 20 months. Suitable to measure consumption over long periods.

The parameter **EN. COUNT.** does not influence the performance of the totalizers divided per time period and does not affect the counters of digital input pulses (optional).

6.3.2 Synchronisation mode

MAIN	
Curr. In	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz.	Auto
Hz	5000
Language	ENG
DMD Time	15
Previous	

The item **Sync.Hz.** (Synchronisation) is used to set the line frequency synchronisation mode.

Move the highlight bar as shown in the

picture; press  to enable, change

 or confirm the selection  The

following options are available:

Auto when the frequency and voltage values are within the measurement range, the instrument is automatically linked with the frequency of the line power measured on the L1 line. When these values are out of the measurement range, the FIXED value, described in the next section, is used.

This option guarantees a more stable measurement of the measured parameters.

Fixed The frequency is set at a fixed value (see next section).

6.3.3 Synchronisation frequency

MAIN	
Curr. In	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz.	Auto
Hz.	5000
Language	ENG
DMD Time	15
Previous	

The item **Hz** (Frequency) is used to set the synchronisation frequency value (see previous paragraph).

Move the highlight bar as shown in the picture;

press  to

enable the selection,  or  move the cursor,  or  change the value,  or confirm it.

6.3.4 Average power integration time (DMD Time)

MAIN	
Curr. In	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz.	Auto
Hz.	5000
Language	ENG
DMD Time	15
Previous	

The item **DMD Time** (Average power integration time) is used to set the calculation time for the displayed average values ("Demand").

Move the highlight bar as shown in the picture; press  to enable,   change, or  confirm the selection. The following

options are available: 1, 5, 10, 15, 30, 60 minutes


NOTE

These values are reset when the instrument is switched on, when quitting the Main Setup menu and after programming the operating parameters by means of the PC software. To obtain real average values, wait for a period as long as the programmed time. The values are updated at the end of the programmed integration time.

MAIN	
Curr. In	CT
Volt. In.	Direct
En. Count.	Fast
B. Light	000
Serial P	232485
Sync. Hz	Auto
Hz.	5000
Language	ENG
DMD Time	15
Previous	


To go back to the Main Setup menu, move the highlight bar to PREVIOUS and press .

6.4 Communication



The communication parameters of the instrument serial port are set in this section.

- 1 In the Main Setup menu, move the highlight bar to COMMUNICATION and press



- 2 To scroll the items press



- 3 To change a parameter, press ,



B. Rate (Baud Rate)

Communication speed on the serial line (300, 600, 1200, 2400, 4800, 9600, 19200, 38400).

NOTE

The IR port must be set at a speed of 9600 to 38400 baud.

Parity

Parity generation (none, even, odd)

Bit

Data bit number (8 fixed).

Stop

Stop bit number (1 fixed).


Address

Logic number assigned to the instrument for the enquiry (hexadecimal, from 01 to FF).

Previous


Returns to the Main Setup menu.

6.5 Memory



This section is used to manage the file storage in the instrument memory.

1 In the Main Setup menu, move the highlight bar to MEMORY and press .



2 To scroll the menu items, press  or



3 To enter the menus press .

6.5.1 Save mode


The instrument saves the data into files. The recording stops when the memory is full.

4 different save processes can be programmed simultaneously (see table below), without downloading the data, and up to 10 measurement campaigns can be executed.

The recording can be programmed according to the start/stop date and time and the number of variables to be stored.

TYPE OF RECORDING	FREQUENCY OR INTEGRATION TIME	CONTINUOUS START/STOP RECORDING	RECORDED UNIT
AVERAGE POWER	Programmable: 1, 5, 10, 15, 30, 60 minutes	Programmable	Programmable options: Active, Reactive Inductive, Reactive Capacitive, Apparent (PURCHASE/SALE)
MINIMUM/MAXIMUM	Programmable: from 1 to 9999 minutes	Programmable	Programmable options: V; V _{L1-N} ; V _{L2-N} ; V _{L3-N} ; I; I _{L1} ; I _{L2} ; I _{L3} ; P; S; PF; Q
SAMPLES	Programmable: from 1 to 9999 secondes	Programmable	Programmable options: V; V _{L1-N} ; V _{L2-N} ; V _{L3-N} ; V _{L1-L2} ; V _{L2-L3} ; V _{L3-L1} ; I; I _{L1} ; I _{L2} ; I _{L3} ; I _N ; PF; PF _{L1} ; PF _{L2} ; PF _{L3} ; Cosφ _{L1} ; Cosφ _{L2} ; Cosφ _{L3} ; S; S _{L1} ; S _{L2} ; S _{L3} ; P; P _{L1} ; P _{L2} ; P _{L3} ; Q; Q _{L1} ; Q _{L2} ; Q _{L3} ; F; THD-V _{L1-N} ; THD-V _{L2-N} ; THD-V _{L3-N} ; THD-I _{L1} ; THD-I _{L2} ; THD-I _{L3} ;
HARMONICS	Programmable: 1, 5, 10, 15, 30, 60 minutes	Programmable	Programmable options: V _{L1-N} ; V _{L2-N} ; V _{L3-N} ; I _{L1} ; I _{L2} ; I _{L3}

6.5.2 File list



This section is used to manage the stored files, delete them or to control the start, stop, information and reset.

Move the highlight bar as shown in the picture and press .

The page shows the stored files; each one contains:

- reference name (e.g.: F 01);
- stored data type (En=average power/energy, Sa=Samples, Ar=Harmonics, Mm=Min/Max);
- file reference logic number (e.g.: 00);
- recording state (Yes/No/Wait);

Press the key  or scroll the options (Info,

Stop etc.)



```

LIST OF FILES
F 01 En 00 N Info
F 02 Sa 01 N Stop
F 03 Ar 02 S St
F 04 Mm 03 S Info
F 05 En 04 N Info
F
F
F
F
F
F
Previous
    
```

Stop

Stop recording;

St

Discontinue recording;

Del

Free up some memory space by deleting the file; the confirmation window is shown before deleting the file (see picture to the side)

Info

Obtain information on the data stored in the file; the window described in the next section is shown.

Can

Make no changes and return to the file list.

```

Delete Files?
YES
    
```

NOTE

For each recording type, only one file can be in St. state.

6.5.3 File information

```

LIST OF FILES
F 01 En 00 N Info
F 02 Sa 01 N Stop
F 03 Ar 02 S St
F 04 Mm 03 S Info
F 05 En 04 N Info
F
F
F
F
F
F
Previous
    
```

Information on the storage file can be obtained through the **Info** function. For access to it, see the previous section.

Type

Type of data stored in the file;

Enable

Recording state (enabled, disabled);

S. Time

Time between two consecutive recordings;

Date

File creation date;

Time

File creation time;

St./Stp

Recording frequency:

CONT.= continuous,

CLOCK= the period is defined in the Start/ Stop window.

```

Type      Min-Max
Enable    Y
S. Time   0001m
Date      02/03/24
Time      15:07:26
St/Stp    CONT.
Params    WIT Y
Size [K]  0000.0701
Active    Y
Previous
    
```

Params

Yes/No indicates the recording state of the indicated variable; to scroll

the available variables, press  then  or 

Size

File size;

Active

Current file use (S= recording , N= not recording);

Previous

Returns to the FILE LIST page.

6.5.4 New file

NEW FILE	
Type	Energy
Enable	Y
S.Time	01 m
St/Stp	CONT.
Params	
Register	
Previous	

This section is used to create a new data storage file. Up to 10 files can be created.

Move the highlight bar as shown in the

picture and press .

Type

Selects the type of data to be stored: En.(average power), Min/Max, Harmonics, Samples;

Enable

Enables / disables the recording;

S. Time

Sets the interval between two consecutive recordings.

Average and harmonic power: 5, 10, 15, 30, 60 min

Samples: from 0000 to 9999 sec.

Min/Max: from 0000 to 9999 min.

St/Stp (Storage interval):

CONT.= continuous;

CLOCK = time interval defined in the Start/ Stop window (see figure to the side and next paragraph).

Params

All selectable values are listed.

Press  or  to scroll the available parameters, press  or  to enable or disable the recording (YES/NO).

Register

Saves the new file and goes back to the MEMORY page.

Previous

Returns to the MEMORY page without saving the new file.

6.5.5 Start/Stop

NEW FILE	
Type	Energy
Enable	Y
S.Time	01 m
St/Stp	CONT.
Params	
Register	
Previous	

To enable this function, set the recording interval (start/stop, see previous paragraph) on CLOCK.

It is used to define the recording start and stop date and time.

St = Recording start

Stp = Recording stop

Date and time

(Date format: yy/mm/dd).

(Time format: hh:mm:ss).

Previous

Returns to the NEW FILE page.

START/STOP	
S Date	02/02/19
S Time	08:00:00
E Date	02/02/19
E Time	18:30:00
Previous	

6.5.6 Formatting

MEMORY	
List of Files	
New File	
Format	
Previous	

This function is use to delete all memory data. The following message is displayed during formatting: WAIT.... FORMATTING.

6.6 Timebands

SETUP	
Main	
Wiring	
Communication	
Printer	
Memory	
Clock	
Timebands	
In/Out - Alarms	

This section is used to program the periods into which energy consumption is divided.

1 In the Main Setup menu, move the highlight bar to TIMEBANDS and press .

TIMEBANDS	
Period	1
Period	2
Period	3
Period	4
Period	5
Period	6
Period	7
Period	8
Period	9
Period	10
Previous	

2 To go to the periods press



3 To access the period press .

PERIOD 1			
Time	1	10:00	0
Time	2	00:00	0
Time	3	00:00	0
Time	4	00:00	0
Time	5	00:00	0
Time	6	00:00	0
Time	7	00:00	0
Time	8	00:00	0
Day		Mon	NO
Month		Jan	NO
Previous			

Up to 10 periods of the year can be programmed.

Up to 8 different daily rates can be programmed for each period. This programme can be linked with different days of the week and months of the year (see the example in the next paragraph).

Time 1...8

Defines the beginning of one or more rate periods in one day (hours:minutes). Up to 8 different rates can be set.

To go to various options, press  or .

To make any changes, press .

To move the cursor to the number press  or . To change it press  or . To confirm press .

The last column on the RH-side is used to set three different periods: **0, 1, 2, 3**. Enter "0" to end the daily programming; no one of the values entered in the following lines will be recognised.

Day

To change it press .

Press  or  to select the day of the week.

Press  or  to include or exclude (YES/NO) the displayed day in the period.

The days that are not selected in any period are automatically assumed as 24 hours, period 3.

Month

To change it press .

Press  or  to select the month.

Press  or  to include or exclude (YES/NO) the displayed month in the period.

The months that are not selected in any period are automatically assumed as having all days in period 3.

NOTE


If the same day or same month are selected in two different periods by mistake, the instrument will retain the programming of the period with the lower number.


Previous

Goes back to the Main Setup menu.



6.6.1 Example of time period programming

The following example (*Example 1*) shows how to program the time periods from October to March.





Example 2



The following table, related to the example 2, summarises the program.

Period	Days	Rates
1	from Monday to Friday	1-2-3
2	Saturday	2-3
	Sunday (not program.)	3 (auto)

7. Technical features

7.1 Available versions

The instrument can be supplied configured as shown in the following table:

CONFIGURATION AND OPTIONS

Serial interface RS232 / RS485	■
Power supply 85-250VAC (90-250VDC)	■
Power supply 19-60VDC	○
Optional slots	4
Digital Outputs (2 outputs are always present) *	○
Digital Input *	○
Analog Output *	○
External Analog output *	○
Ethernet	○
Lonbus *	○
Profibus *	○
Protocollo Modbus	■
Oscilloscope / Histogram	■
Harmonic analysis (50)	■
WFR (14 ... 500Hz)	○
VDROP	○
VMAX	○
Printer LPR40	○

■ - AVAILABLE ○ - OPTIONAL

* max. 4 options

7.2 Technical data

Auxiliary supply voltage

85 ÷ 250 VAC 50 / 60 Hz or 90 ÷ 250 VDC (19 ÷ 60 VDC upon request).
 Max. repetitive voltage: 300VAC.
 Max. non-repetitive peak voltage: 320VAC (20 msec).
 Consumption: 6 ÷ 12VA (according to the installed options) .
 Fuse: type T, 315mA (to be mounted externally).

Safety conditions

The instrument was manufactured and tested in compliance with the CEI EN61010-1 (1993) regulations and relevant amendments, CEI EN61010-1/A2 (1995) and UL 61010A-1 (2002), for working voltage up to 750 VAC rms.

Overvoltage category : III

Polluting level : 2

Voltmetric inputs

Voltage: 750 VAC max L-L

Max continuous overload:

1000Vrms L-L o L-N

600Vrms L- \perp

Max acceptable peak:

2kVrms L-L o L-N (1sec)

1kVrms L- \perp

Input impedance: > 1,3 MOhm

Load: max 0.15 VA per phase @ F.S.

Current input

Current: 1A or 5 A, programmable

Min / Max measurable current: 20mA / 7A

Max overload: 10A continuous, 100A for 1 sec.

Input impedance: approx. 0.02 Ohm

Load: Max 0.05VA per phase

Insulation: Max. 150Vrms between phases

Instrument precision

Voltage: $\pm 0.2\%$ reading $\pm 0.05\%$ full scale

Current: $\pm 0.2\%$ reading $\pm 0.1\%$ full scale

Powers: $\pm 1\%$ reading $\pm 0.1\%$ full scale (PF=1)

Power factor: 1% reading (0.5 inductive ÷ 0.8 capacitive)

Active energies: 1.5% reading (0.5 inductive ÷ 0.8 capacitive)

Frequency: $\pm 0.05\%$ reading ± 2 digit from 45 to 65Hz

Harmonic analysis: 0.5% (with measured harmonic component above 3% and input voltage and current above 10% of scale bottom).

Measurement range

Automatic frequency linking when the measurement frequency is comprised between 45 and 65 Hz (V_{L1-N} min. 10V).

A fixed value can be manually set (between 45 and 65 Hz).

Thanks to the WFR option, the measurement range is expanded to: 14-500Hz.

Measurement method

32 samplings per period for 8 periods; total: 256 samplings per measure (sampling frequency at 50 Hz: 1.6 kHz).

Harmonic analysis: carried out up to the 50th harmonics by means of the FFT method, simultaneously on 3 voltages and 3 currents.

Measurement frequency: 1 second (10 seconds for harmonics and THD).

Recording frequency: programmable.

Serial output

RS232 / 485 / switch-selectable PRINTER.

Baud rate programmable up to 38400.

Protocol: standard ASCII (Modbus upon request).

IR port

Baud rate programmable from 9600 to 38400.

Half duplex

Max. allowed distance: 1m.

Optical range $\pm 15^\circ$ (minimum), $\pm 30^\circ$ (maximum).

Input/output

The instrument has two digital outputs.

The optional parts include modules that can be easily installed on the back. Four slots are available for the installation of optional parts.

Each module is composed of:

N° 4 Isolated digital inputs for voltage-free contacts.

N° 2 / 4 Opto-insulated outputs for threshold alarms or pulse transmission.

N° 2 0-20 or 4-20mA active analog inputs, galvanic isolation.

Display

Backlit LCD graphic display, 128x128. Working life of background lighting: > 100.000 ore.

Keypad

5 keys on the front panel.

Data recording

RAM 2MB. The following data can be saved:

- instantaneous values;
- min./max. values;
- harmonic content;
- average power.

Data recording without power supply

The calibration and programming parameters are saved in the memory for an unlimited period of time.

Clock

Precision: ± 5 sec. / day at 25°C (powered).

Information retaining time: 30 days

Automatic adjustment to leap years.

Programmable parameters

The instrument calibration and programming parameters are saved in an EEPROM-type non volatile memory.

The data are retained in the instrument, even if not switched on for 40 years.

Environmental conditions

Working temperature: from -10°C to +60 °C (from 14 to 140 °F).

Storage temperature: from - 20° to +75°C (from - 4 to 167 °F).

Working humidity: Max. 80%, non condensing for a temperature up to a 31°C (87.8 °F); linear decrease up to 40°C (104 °F).

Altitude: up to 2000m

Sizes

Casing 144 x 144 x 118 mm.

Weight

About 1500 g.

7.2.1 Electromagnetic compatibility

Immunity: as per EN50082-2

- Electrostatic discharges (as per EN 61000-4-2)
8kV in air - level 3
4kV, contact - level 2
- Irradiated electromagnetic field (as per EN 61000-4-3)
10 V/m - level 3
- Transients (as per EN 61000-4-4)
2kV - level 3
- Ridge (as per EN 61000-4-5)
1/2kV - 1,2/50µs

Emission: as per EN 50081-2

- Radiated EN55011
class A – group 1
- Mains EN55011
class A – group 1

7.3 Performed measurements

TYPE OF MEASUREMENT	UNIT'	SUPPLIED
PHASE VOLTAGE (rms)	$V_{L1-N} - V_{L2-N} - V_{L3-N}$ [V]	■
LINE VOLTAGE	$V_{L1-L2} - V_{L2-L3} - V_{L3-L1}$ [V]	■
SYSTEM VOLTAGE	V [V]	■
LINE CURRENT	$I_{L1} - I_{L2} - I_{L3} - I_N$ [A]	■
SYSTEM CURRENT	I [A]	■
POWER FACTOR	$PF_{L1} - PF_{L2} - PF_{L3}$	■
SYSTEM POWER FACTOR	PF	■
COS Ø	$DPF_{L1} - DPF_{L2} - DPF_{L3}$	■
APPARENT POWER	$S_{L1} - S_{L2} - S_{L3}$ [VA]	■
APPARENT SYSTEM POWER	S [VA]	■
ACTIVE POWER	$P_{L1} - P_{L2} - P_{L3}$ [W]	■
ACTIVE SYSTEM POWER	P [W]	■
REACTIVE POWER	$Q_{L1} - Q_{L2} - Q_{L3}$ [var]	■
REACTIVE SYSTEM POWER	Q [var]	■
FREQUENCY	f [Hz]	■
ACTIVE SYSTEM ENERGY (INPUT)	Wh	■
APPARENT SYSTEM ENERGY (INPUT)	VAh	■
INDUCTIVE REACTIVE SYSTEM ENERGY (INPUT)	varh ind	■
CAPACITIVE REACTIVE SYSTEM ENERGY (INPUT)	varh cap	■
ACTIVE SYSTEM ENERGY (OUTPUT)	Wh	■
APPARENT SYSTEM ENERGY (OUTPUT)	VAh	■
INDUCTIVE REACTIVE SYSTEM ENERGY (OUTPUT)	varh ind	■
CAPACITIVE REACTIVE SYSTEM ENERGY (OUTPUT)	varh cap	■
AVERAGE VALUES (OR PEAK)	$I - V_{L1/L2/L3/N} - P - S - Q - PF$	■
MIN/MAX VALUES	$V - V_{L1-N/L2-N/L3-N} - I - I_{L1/L2/L3}$ $P - S - PF - P_{AV}$	■
INDEX OF VOLTAGE HARMONIC DISTORTION	$THD_{L1} - THD_{L2} - THD_{L3}$ [%]	■
INDEX OF CURRENT HARMONIC DISTORTION	$THD_{L1} - THD_{L2} - THD_{L3}$ [%]	■
FFT ANALYSIS		■
TIME PERIODS	Wh-VAh-varh ind-varh cap	■

■ - AVAILABLE ○ - OPTIONAL

7.4 Formulas

PHASE VOLTAGE	3-PHASE SYSTEM VOLTAGE
$V_{L1-N} = \sqrt{\frac{1}{n} * \sum_{j=1}^n (V_{L1-N})_j^2}$	$V = \frac{V_{L1-L2} + V_{L2-L3} + V_{L3-L1}}{3}$
LINE VOLTAGE	
$V_{L1-L2} = \sqrt{\frac{1}{n} * \sum_{j=1}^n ((V_{L1-N})_j - (V_{L2-N})_j)^2}$	
LINE CURRENT	3-PHASE SYSTEM VOLTAGE
$I_{L1} = \sqrt{\frac{1}{n} * \sum_{j=1}^n (i_{L1})_j^2}$	$I = \frac{I_{L1} + I_{L2} + I_{L3}}{3}$
NEUTRAL CURRENT	
$I_n = \sqrt{\frac{1}{n} * \sum_{j=1}^n ((i_{L1})_j + (i_{L2})_j + (i_{L3})_j)^2}$	
ACTIVE POWER	3-PH. SYSTEM ACTIVE POWER
$P_{L1} = \frac{1}{n} * \sum_{j=1}^n (V_{L1-N})_j * (i_{L1})_j$	$P = P_{L1} + P_{L2} + P_{L3}$
REACTIVE POWER	3-PH. SYST. REACTIVE POWER
$Q_{L1} = \frac{1}{n} * \sum_{j=1}^n (V_{L1-N})_j * (i_{L1})_{j-\frac{\pi}{2}}$	$Q = Q_{L1} + Q_{L2} + Q_{L3}$
APPARENT POWER	3-PH. SYST. APPAR. POWER
$S_{L1} = V_{L1-N} * I_{L1}$	$S = \sqrt{3} * V * I$
POWER FACTOR	3-PH. SYST. POWER FACTOR
$PF_{L1} = \frac{P_{L1}}{S_{L1}}$	$PF = \frac{P}{S}$

7.5 Functions available upon request

7.5.1 Communication protocol

For communication through standard RS232/485 interface, the instrument is supplied with a customised protocol.

The MODBUS protocol is also available and must be specified in the order.

The instrument can also be integrated in ETHERNET, LONBUS or PROFIBUS networks by means of optional communication cards.

7.5.2 Power supply

The standard instrument can be connected to 65 to 250 VAC or 90 to 250VDC mains; no operations are needed to change the voltage.

Upon request, the instrument can be equipped with a 19 to 60 VDC power supply.

7.5.3 Voltage drops

Thanks to the VDROP option, the instrument is capable of continuously monitoring the three voltage values with a 10 ms resolution. The detected data are compared with the set threshold values and saved together with the date and time of the event.

Thanks to the DEDALO software (see next paragraph) the data can be statistically analysed, in compliance with EN50160 norms on energy quality.

7.5.4 Minimum, average and maximum values

The MIN/MED/MAX function calculates the minimum, average and maximum values of 10 variables chosen among the ones that the instrument can measure, thanks to a continuous sampling procedure. These values are stored in the CPU2 RAM.

Thanks to the DEDALO software (see next paragraph) the data can be statistically analysed, in compliance with EN50160 norms on energy quality.

7.5.5 LPR40 Printer

The LPR40 allows the instrument to print the detected data. The operation can be manual or automatic (for further details, please refer to the LPR40 documentation).

The printer can also be set from the instrument keypad. Graphic, numeric or histogram prints can be made. In automatic mode the print start and stop time and the requested frequency can be pre-set.

7.6 Software

7.6.1 Wintool

The Wintool software is provided free of charge.

Connect the instrument to the PC serial port for the software to carry out the following operations:

- numeric display of the instantaneous values measured by the instrument;
- instrument programming;
- transfer the text files recorded on CPU2 (VDROP and MIN/MED/MAX) to the PC.

7.6.2 Dedalo SP

The DEDALO SP software is available in 4 different versions; it expands WINTOOL functions and adds some new ones.

	Istantaneous	Programming	Transfer	Print	Alarms	Modem	Recording on file	Graphic analysis	File export
DEDALO SP	✓	✓	✓						
DEDALO SP P	✓	✓	✓	✓	✓	✓			
DEDALO SP A	✓	✓	✓				✓	✓	✓
DEDALO SP AP	✓	✓	✓	✓	✓	✓	✓	✓	✓

Istantaneous

Display of the instantaneous values measured by the instrument. To facilitate the analysis, the data can be shown in a numeric or graphic format.

The following values can be displayed:

- any instantaneous value (voltage, current, power, PF, etc.)
- Energies
- Harmonics up to the 64th level
- Voltage and current wave shape
- Chart of measured values
- Index indicators

Programming

Instrument programming by means of the software vs. keypad.

Download

Transfers the data recorded by the instrument on PC in a text file.

Prints

Prints the values measured according to a pre-set frequency.

Alarms

The user can set 8 threshold values for as many measurements. When a threshold is exceeded a graphic or sound alarm is sent out. All the alarms are recorded in a file containing date and time data, max and min. detected values and can be printed out.

Modem

It is used to display the measured values, program the instrument and transfer the data recorded by an instrument that is not connected with the PC (remote). The last function requires a modem and a telephone line.

Recording on file

The values measured by the instrument can be saved into a file on the hard drive.

Graphic analysis

The historical data can be analysed as charts or tables and charts of daily consumption can be plotted.

Export file

It is used to export the data recorded in the instrument by means of text files or spreadsheets.

algodue[®]
ELETTRONICA

via Passerina, 3 / A - 28010 FONTANETO D'AGOGNA (NO) - ITALY

Tel. + 39 0322 89864 / 89307 / 89871 (fax)

Internet: <http://www.algodue.com> - E-mail: info@algodue.com

WARNING - ALGODUE declines all liability for any damage to people or property caused by incorrect use of this product. Subject to change without prior notice